

## Primo Touch Menu Options

Drink Options	Touch 3	Touch 4
Coffee (thermos jugs)	✓	✓
Coffee with Milk	✓	✓
Coffee with Sugar	⊗	✓
Coffee, Milk & Sugar	⊗	✓
Espresso	✓	✓
Cappuccino	✓	✓
Latte Macchiato	✓	✓
Coffee Choc	✓	✓
Chocolate Milk	✓	✓
Wiener Melange	✓	✓
Hot Water	✓	✓
Espresso Choc	✓	✓
Decaf	⊗	⊗
Tea	⊗	⊗
Hot Milk	⊗	⊗
Hot Chocolate	⊗	⊗
Double Espresso	⊗	⊗
Instant Coffee	⊗	⊗
Instant Tea	-	⊗

✓ Standard Factory Settings

⊗ Adjustable (Depending on chosen ingredients)